

Installation Guide for the SCM Swapbox PnP Card Drives Application Note
SCM SBP-D2P, SBP-C2CP, SBP-C1P, SBI-C2CP & SBI-D2P for Windows NT

1. Before installing the PCI card into the slot, turn computer on and boot into Windows NT. Goto *Start, Settings, Control Panel*. Find the *Devices* Icon double click on it. Set the **PCMCIA** service to **Boot**. Reboot the system for changes to take effect.
2. Before Reboot is finished you must get into your system's BIOS (*consult your PC User's Manual for instructs on how to access the BIOS settings*).
3. In the BIOS setting make sure your Plug-n-Play option is turned to the **OFF** setting. Windows NT does not support Plug-n-Play (*again check your PC User's Manual for instructions on how to get to the settings*). Once the settings are applied exit the BIOS and shutdown the system.
4. Install the reader and PCI card into the selected slot and bay. Turn computer on.
5. Once Windows NT is done rebooting and you are at the desktop place the CD *Resources Disk* into the CD ROM. Double click on *MY Computer*, then double click the CD-ROM drive.
6. Once opened goto the *Cardware* folder and double click, open *Disk 1* folder and double click, find the *Setup.exe* file and double click to initiate the setup program.
7. Follow the default options by clicking the *Next* button until all the files are copied and the setup is finished. Reboot the PC. Place the PCMCIA card into the reader before it finishes rebooting.
8. When you reboot *Cardware* creates a different profile called *Touchstone Cardware Configuration*. It also gives you the option of selecting the original configuration too however, being that a PCMCIA card is to be read you must select the *Touchstone* configuration.
9. Once reboot is finished your reader is now ready to be used.

NOTE: For the SBI-D2P model reader the *Cardware* software is **NOT Included** with the reader. You must purchase the software. To purchase the *Cardware* goto www.unicore.com